

Items Supplied >

- 1 – Fi2000R Fuel Injection Module
- 2 – Zip Ties, (1): 3/32" x 6"; & (1): 3/16" x 8"
- 1 – Velcro Strip

Application(s) >

- Kawasaki 1500P Meanstreak 02-03
- Kawasaki 1600 Meanstreak 04-08
- Suzuki Marauder 1600 2004

Instruction Manual >

92-1962R

Page 1 of 3

Read all instructions carefully and completely before installing your new Fi2000R module. It is recommended that a qualified mechanic or technician install this product. Before installing the Fi2000R it is recommended that the gas tank be low on fuel.

1. Remove the seat, and then remove the Allen head bolts securing the chrome dash on the fuel tank. Pull the dash rearwards until it releases from its locating pins, then turn the dash over and unplug the two harness connectors.
2. Remove the bolt from the rear of the fuel tank, disconnect the two hoses next to the bolt and then lift the tank enough to access the hoses underneath. Disconnect both fuel lines, the fuel pump wiring connectors and the vent hose and then lift the tank away. Place it safely aside.
3. Place the Fi2000R module near the fuel tank, and feed the wires under the frame forward of the battery and up the right side of the bike following the stock wiring harness. Locate the fuel injector connectors and release them by pushing the lock tab while pulling gently on the connector. Note, which is front and rear, as they are *NOT* marked. Now plug the Fi2000R gray connectors on to the injectors, the long Fi2000R harness lead plugs into the front cylinder injector, Figure 1. Reattach the original injector connectors into the corresponding black Fi2000R connectors.
4. Ziptie the Fi2000R harness to the stock harness, Figure 2. Replace the fuel tank, making sure all the hoses, wires and bolts are properly reconnected
5. Using the supplied Velcro pads, place the module in the position shown, in Figure 2. Attach the black ground wire from the Fi2000R to the negative post of the battery. Before reinstalling the seat, verify connections.
6. Remove the door from the Fi2000R module to expose the LED's. **NOTE:** The Fi2000R pot settings come preset from the factory for the Meanstreak / Marauder 1600, (Fig.3), for owners, with the Meanstreak 1500 please adjust the Fi2000R to the base pot settings shown in (Fig. 4), prior to proceeding further. Verify the wire connections by turning the ignition on, prior to starting, and see if all three LEDs are on steady for a few seconds, and then go off. This is correct. If there are no lights visible, make sure the side stand is up, bike is in neutral, clutch is in and handlebar engine switch is set to run. If there are still no lights visible, re-check that all connectors are fully engaged and the ground wire is connected correctly.

** For California riders we offer Air Resources Board approved Fi2000 ARB units with Executive Order number D-633-2. All other Fi2000 models are not legal for street use in California.*

7. After achieving a steady light from all three LEDs, start the motorcycle and let it idle. While the bike is idling all three LEDs should be on steady. When the RPMs go above 1500 the yellow and red LEDs will turn off and the green LED will stay on steady. To check this, wait at least 10 seconds after starting the engine and then raise the engine speed to 1500-2000RPMs. If the green LED is the only LED on steady, then all connections have been made correctly.
8. If all three LED's are still on after start up verify the injector connectors are correctly attached. Reattach the access door when finished and install remaining components. **NOTE:** Make sure the ignition is turned off before changing any connection.

ADVANCED TUNING

The Fi2000R has the ability to efficiently tune the EFI system on your motorcycle for slip-on or full exhaust systems. It comes pre-set from the factory for popular brand name slip-on mufflers. Both dyno testing and on-road exhaust gas analysis have been used to develop the best base settings for drivability and power. Not all slip-on mufflers flow exactly the same. Some eliminate power valves and others don't. Some are made with street baffles, other with race or competition baffles. Full exhaust systems offer even greater variation in construction, features and performance. The Fi2000R has the ability to tune the EFI system on your motorcycle to any of these exhausts by applying a logical and systematic approach to altering the base settings supplied with your Fi2000R. These suggestions should be followed step by step and help you achieve success.

**** Only attempt adjustments on a fully warmed motor ****

1. Start with the base setting, even if you have a full exhaust system. Adjust and test only *ONE* adjustment pot at a time until you are happy with the result.
2. Start with the left hand or green light pot. This adjustment works either from idle or above idle (varies with bike) to a R.P.M. of about 5000 (also varies with bike) while the bike is driven at a steady throttle or slowly increasing throttle. This is the cruise range and is where the emissions leanness creates issues like choppy on-off throttle application, surging, and backfiring on trailing throttle.
3. Turn this pot back to zero, and make one position increases until you feel the best performance in this range. Do this test a few times to make sure you have it right.
4. The middle or yellow pot is an engine load- triggered fuel adding adjustment. A rapid increase of the throttle at any R.P.M. will add additional fuel and as long as that predetermined load is present, fuel will continue. As engine loads increase in higher gears the acceleration fuel will stay on longer and be more effective. Starting with the base setting, test ride the motorcycle in 4th or 5th gear and perform moderately fast roll-on throttle from a repeating standard R.P.M. or speed. Increase the pot one position at a time and stop as soon as you don't feel any improvement.
5. The right hand or red pot is for the fuel setting required when the engine is maximizing its R.P.M. and power delivery. This pot is similar to the main jet in a carburetor. It will take a combination of a minimum R.P.M. and a predetermined amount of engine load to initiate this fuel. The straightaway on a racetrack or an inertia dyno are the best places to set this pot. Full exhaust systems of high quality construction increase flow characteristics and will increase fuel demands over our base settings. Also, air filters specifically designed for higher than stock airflow can create need for higher fuel setting. Try an additional one-position pot setting at a time.
6. Camshaft changes can alter an engine's volumetric efficiency and create a greater demand on the engine's fuel system than the Fi2000R may have the ability to adjust for.

TROUBLE SHOOTING Tech Support <https://fi2000.com>

If you have any problems refer to: Step 6, in the installation body of these instructions.




FIGURE 1




FIGURE 2

MEANSTREAK / MARAUDER 1600

Default Pot Settings:

2.5 4.5 0




FIGURE 3

MEANSTREAK 1500

Default Pot Settings:

1.5 5 0




FIGURE 4